# Report

April 14, 2019

# 1 Assignment -5 Optical Flow

Rollno: 2018201097

Name: Aman Joshi

## 1.1 Optical Flow:

Optical flow or optic flow is the pattern of apparent motion of objects, surfaces, and edges in a visual scene caused by the relative motion between an observer and a scene. Optical flow can also be defined as the distribution of apparent velocities of movement of brightness pattern in an image. We assume that the Intensities of point doesn't change between respective frames.

$$I(x,y,t) = I(x + \Delta x, y + \Delta y, t + \Delta t)$$

$$I(x + \Delta x, y + \Delta y, t + \Delta t) = I(x,y,t) + \frac{\partial I}{\partial x} \Delta x + \frac{\partial I}{\partial y} \Delta y + \frac{\partial I}{\partial t} \Delta t + H.O.T.$$
 (1)

From Equation 1 we have

$$\frac{\partial I}{\partial x} \Delta x + \frac{\partial I}{\partial y} \Delta y + \frac{\partial I}{\partial t} \Delta t = 0$$

$$\frac{\partial I}{\partial x} \frac{\Delta x}{\Delta t} + \frac{\partial I}{\partial y} \frac{\Delta y}{\Delta t} + \frac{\partial I}{\partial t} \frac{\Delta t}{\Delta t} = 0$$


$$\frac{\partial I}{\partial x} V_x + \frac{\partial I}{\partial y} V_y + \frac{\partial I}{\partial t} = 0$$

```
Iy[1:-1, 1:-1] = cv.subtract(frame1[2:, 1:-1], frame1[:-2, 1:-1]) / 2
             It[1:-1, 1:-1] = cv.subtract(frame1[1:-1, 1:-1], frame2[1:-1, 1:-1])
             params = np.zeros(frame1.shape + (5, ))
             params[..., 0] = Ix**2
             params[..., 1] = Iv**2
             params[..., 2] = Ix * Iy
             params[..., 3] = Ix * It
             params[..., 4] = Iy * It
             del It, Ix, Iy
             cum_params = np.cumsum(np.cumsum(params, axis=0), axis=1)
             del params
             win_params = (cum_params[2 * win + 1:, 2 * win + 1:] -
                           cum_params[2 * win + 1:, :-1 - 2 * win])
             win_params -= cum_params[:-1 - 2 * win, 2 * win + 1:]
             win_params += cum_params[:-1 - 2 * win, :-1 - 2 * win]
             del cum_params
             op_flow = np.zeros(frame1.shape + (2, ))
             det = win_params[..., 0] * win_params[..., 1] - win_params[..., 2]**2
             op_flow_x = np.where(det != 0,
                                  (win_params[..., 1] * win_params[..., 3] -
                                   win_params[..., 2] * win_params[..., 4]) / det, 0)
             op_flow_y = np.where(det != 0,
                                  (win_params[..., 0] * win_params[..., 4] -
                                   win_params[..., 2] * win_params[..., 3]) / det, 0)
             op_flow[win + 1:-1 - win, win + 1:-1 - win, 0] = op_flow_x[:-1, :-1]
             op_flow[win + 1:-1 - win, win + 1:-1 - win, 1] = op_flow_y[:-1, :-1]
             op_flow = op_flow.astype(np.float32)
             return op_flow
In [29]: def draw_flow(img, flow):
             x = np.arange(0, img.shape[1], 1)
             y = np.arange(0, img.shape[0], 1)
             x, y = np.meshgrid(x, y)
             plt.figure()
             fig = plt.imshow(img, cmap='gray', interpolation='bicubic')
             plt.axis('off')
             fig.axes.get_xaxis().set_visible(False)
             fig.axes.get_vaxis().set_visible(False)
             step = img.shape[0] / 20
             step = int(step)
             plt.quiver(
                 x[::step, ::step],
                 y[::step, ::step],
                 flow[::step, ::step, 0],
                 flow[::step, ::step, 1],
                 color='r',
```

```
pivot='middle',
    headwidth=2,
    headlength=3)

plt.axis('off')
    plt.show()


In [30]: image1 = cv.imread("eval-data-gray/Basketball/frame10.png", 0)
    image2 = cv.imread("eval-data-gray/Basketball/frame11.png", 0)
    flow = optical_flow(image1, image2, 15)
    draw_flow(image1, flow)
```







flow = optical\_flow(image1, image2, 15)
draw\_flow(image1, flow)





### 1.1.1 Detection and segmentation of moving objects in a video

Implementation Details: - Get the flow between consecutive frames of a video - Using cv2.cartToPolar() function get the magnitude of flow - Apply thresholds and convert the magnitude array to hsv for better visualization

```
In [35]: cap = cv.VideoCapture("vtest.avi")
         ret, frame1 = cap.read()
         prvs = cv.cvtColor(frame1, cv.COLOR_BGR2GRAY)
         hsv = np.zeros_like(frame1)
         hsv[..., 1] = 255
         count = -1
         while True:
             ret, frame2 = cap.read()
             count += 1
             if count % 200 != 0:
                 continue
             if ret is False:
                 break
             next = cv.cvtColor(frame2, cv.COLOR_BGR2GRAY)
             flow = optical_flow(prvs, next, 24)
             mag, ang = cv.cartToPolar(flow[..., 0], flow[..., 1])
             hsv[..., 0] = ang * 180 / np.pi / 2
             hsv[..., 2] = cv.normalize(mag, None, 0, 255, cv.NORM_MINMAX)
             rgb = cv.cvtColor(hsv, cv.COLOR_HSV2BGR)
             plt.subplot(1, 2, 1)
             plt.imshow(cv.cvtColor(frame2, cv.COLOR_BGR2RGB))
             plt.axis("off")
             plt.subplot(1, 2, 2)
             plt.imshow(cv.cvtColor(rgb, cv.COLOR_BGR2RGB))
             plt.axis("off")
             plt.show()
             prvs = next
         cap.release()
```



















### 1.1.2 Tracking of objects in a video sequence


Implementation Details: - Get the flow between consecutive frames of a video - Using cv2.cartToPolar() function get the magnitude of flow - Convert the magnitude array to hsv and apply thresholds to get the dominant areas - Find the contours using cv2.findContours() method from the thresholded magnitude array - Draw bounded boxes for the different countours


```
In [36]: def draw_hsv(flow, prev, change=True):
             hsv = np.zeros_like(prev)
             hsv[..., 1] = 255
             mag, ang = cv.cartToPolar(flow[..., 0], flow[..., 1])
             hsv[..., 0] = ang * 180 / np.pi / 2
             hsv[..., 2] = cv.normalize(mag, None, 0, 255, cv.NORM_MINMAX)
             if change:
                 hsv = cv.cvtColor(hsv, cv.COLOR_HSV2BGR)
             return hsv
In [37]: def track_moving_objects(frame, prev):
             def gray(img):
                 return cv.cvtColor(img, cv.COLOR_BGR2GRAY)
             flow = optical_flow(gray(prev), gray(frame), 24)
             hsv1 = draw_hsv(flow, prev)
             gray1 = cv.cvtColor(hsv1, cv.COLOR_BGR2GRAY)
             thresh = cv.threshold(gray1, 25, OxFF, cv.THRESH_BINARY)[1]
             thresh = cv.dilate(thresh, None, iterations=2)
             cnts, hierarchy = cv.findContours(thresh.copy(), cv.RETR_EXTERNAL,
                                               cv.CHAIN APPROX SIMPLE)
             for c in cnts:
                 (x, y, w, h) = cv.boundingRect(c)
                 if w > 15 and h > 15 and w < 900 and h < 680:
```

```
cv.rectangle(frame, (x, y), (x + w, y + h), (0, 0xFF, 0), 4)
             return frame
In [38]: cap = cv.VideoCapture("vtest.avi")
         ret, frame1 = cap.read()
         count = -1
         while True:
             ret, frame2 = cap.read()
             count += 1
             if count % 200 != 0:
                 continue
             if ret is False:
                 break
             objected_frame = track_moving_objects(frame2, frame1)
             plt.imshow(cv.cvtColor(frame2, cv.COLOR_BGR2RGB))
             plt.axis("off")
             plt.show()
             prvs = next
         cap.release()
```









```
In [39]: cap = cv.VideoCapture("test.mp4")
         ret, frame1 = cap.read()
         count = -1
         while True:
             ret, frame2 = cap.read()
             count += 1
             if count % 200 != 0:
                 continue
             if ret is False:
                 break
             objected_frame = track_moving_objects(frame2, frame1)
             plt.imshow(cv.cvtColor(frame2, cv.COLOR_BGR2RGB))
             plt.axis("off")
             plt.show()
             prvs = next
         cap.release()
```

/home/aman/anaconda3/lib/python3.6/site-packages/ipykernel\_launcher.py:29: RuntimeWarning: divided home/aman/anaconda3/lib/python3.6/site-packages/ipykernel\_launcher.py:29: RuntimeWarning: inval/home/aman/anaconda3/lib/python3.6/site-packages/ipykernel\_launcher.py:32: RuntimeWarning: divided home/aman/anaconda3/lib/python3.6/site-packages/ipykernel\_launcher.py:32: RuntimeWarning: inval/home/aman/anaconda3/lib/python3.6/site-packages/ipykernel\_launcher.py:32: RuntimeWarning: inval/home/aman/anaconda3/lib/python3/home/aman/anaconda3/lib/python3/home/aman/anaconda3/lib/python3/home/aman/anaconda3/lib/p

